

rSSD 7101A

PCIe 3.0 x16 NVMe RAID Controller with E-Class SSDs

Quick Installation Guide

V1.0.0

Applicable Products

- rSSD 7101A-500G
- rSSD 7101A-010T
- rSSD 7101A-020T
- rSSD 7101A-040T

Kit Content

- Pre-config NVMe RAID Drive
- Quick Installation Guide

Setup

1. Place your rSSD drive to a PCIe 3.0x16 slot for maximum performance
2. Download files from http://www.highpoint-tech.com/USA_new/CS-product_nvme_drive_download.htm
3. Open the rSSD Manager folder, run rSSD Manager, and follow the onscreen instructions
4. Open the Driver folder, run Setup, and follow the onscreen instructions
5. Restart the computer
6. Open the rSSD Manager Application and select the Setting tab on the top. Under Enclosure Info, make sure the Link Width is x16 and Link Speed is 8.0 GT/s to ensure maximum performance.

Enclosure(1): rSSD7101x

HighPoint
Technologies, Inc.

Overview Quick Config. Advanced Config. **Settings** Event SHI Help

Enclosure

Email Notification

Security

System

Enclosure Info

Product Name: rSSD 7101x

PCI Bus Number: 2

PCI Device Number: 0

Link Width: x16

Link Speed: 8.0 GT/s

0106

Customer Support

If you encounter any problems with the rSSD 7101A or have any questions regarding this or any other HighPoint Technologies, Inc. product, feel free to contact our Customer Support Department

Web Support:

<http://www.highpoint-tech.com/websupport>

HighPoint Technologies, Inc. Website:

<http://www.highpoint-tech.com>

© Copyright 2017 HighPoint Technologies, Inc. All rights reserved.